

**MF 1100 Series
Quick-tach Stomper**



- 1) Remove 4 bolts and nuts
- 2) Remove bracket and discard (will no longer be needed)
- 3) Install stomper bracket using existing bolts and tighten
- 4) Install stomper shoe with quick pin in the highest mounting position

